



16 AB

16 AB

No BULOVA	Caliber reference	No BULOVA	Caliber reference
1	16 AB	59	16 AB
2	16 AB	60	16 AB
4	16 AB	61	16 AB
5	16 AB	62 A	16 AB
6	16 AB	63	Ø 100
7	16 AB	64	Ø 200
8	16 AB	65	Ø 28
11	16 AB	70 L	16 AB
13	16 AB	70 R	16 AB
14	16 AB	35 A	16 AB
15	16 AB	36	16 AB
16	16 AB	111	17 AH
17	16 AB	112	16 AB
18	16 AB		
23	16 AB		
24	16 AB		
25	16 AB		
26	16 AB		
28	16 AB		
29	16 AB		
30 A	16 AB		
31	16 AB		
32	16 AB		
35	16 AB		
37-38	16 AB		
39	16 AB		
40	16 AB		
41	16 AB		
42	16 AB		
44	16 AB		
45	16 AB		
47	16 AB		
48	16 AB		
51	16 AB		
53	16 AB		
54	16 AB		
55 A	16 AB		
56	16 AB		
57	16 AB		
58	16 AB		



{ Página 50, Seite 50,
Página 50, Seite 50,